


Scenario 1: DC-Coupled with Meter(DTSU666)


3. Distribute the power of all loads as evenly as possible across the three phases.



The icon "☎" on the display will flash when the meter communication is successful.

Scenario 2: AC-Coupled with Meter(DTSU666)

- Note:** 1.The arrow on all the CTs must point toward the GRID.
2.Please use an energy meter with the “**KSTAR**” logo.
3.Distribute the power of AC-coupled inverters and all loads as evenly as possible across the three phases.



The icon "☎" on the display will flash when the meter communication is successful.